

STOP!

CRITICAL INSTALLATION STEPS

1. DO NOT UNLOCK SASH OR REMOVE INSTALLATION SETTING BLOCKS LOCATED BETWEEN THE SASH AND FRAME PRIOR TO SECURING THE FRAME INTO THE ROUGH OPENING.
2. TAKE CARE TO MAINTAIN AN EVEN REVEAL (SPACING) BETWEEN THE PERIMETER OF THE SASH AND FRAME DURING INSTALLATION.
3. AFTER INSTALLED, REMOVE SETTING BLOCKS FROM BOTH STILES AND BOTTOM RAIL OF THE SASH.

